METEX

SCREEDPOD

Screedpod – Liquid Screed Levelling Tripod

Instructions for use

Site Preparation

Determine the desired level of the finished screed, known as the datum level.

The datum level is likely to be an offset distance from a fixed point, such as the final finished floor level or a door sill.

Place a Screedpod next to this datum point and adjust the height of the Screedpod disc by rotating the handle until the disc is approximately at the same level as the datum point. Then set the disc height exactly to match the datum level using a laser level or spirit level.

Leave this datum Screedpod in position and place additional Screedpods throughout the area to be screeded. We recommend a spacing of 1500mm between Screedpods, however this can be adjusted to suit.

Set a laser level to the datum Screedpod DISC and then transfer this level to each additional Screedpod DISC in turn, adjusting height of each DISC until they are all set at the datum level.

Always set the level directly to each DISC.

Pouring Screed

Pour screed up to the datum level, which is set by each Screedpod disc, ensure that there are no high or low areas of screed between each Screedpod.

Once the screed has been poured remove all Screedpods from site.

Cleaning Screedpods

Clean each Screedpod carefully immediately after it has been removed to prevent screed hardening on the Screedpod. Ensure all traces of screed have been removed, paying particular attention to the thread.

Screedpod threads should be lubricated periodically to prolong life.